



COMPACTLEES



CompactLees

Riddling aid for bottle fermentation of sparkling wine

The silicates composition causes rapid agglomeration with the yeast sediment, which optimises the riddling process through full and rapid yeast sedimentation.

At a glance:

Product Silicate suspension

Range of use Traditional "méthode champenoise" bottle fermentation



Goal Compacts the sediment deposit in a much shorter time

Special features

Faster sediment deposition prevents yeast adhesion to the bottle wall

Several riddling steps can be performed per day

Dosage 50 - 70 mL/100 L cuvée

Packaging unit 1 kg

10 kg